





Cordless Chain Saw

Item No.: 4501760

Ident No.: 11015

Bar Code: 4006825608335

The Einhell cordless GE-LC 18 Li Chainsaw Kit combines the outstanding performance of an Einhell product with a high-quality OREGON guide bar and chain. Kickback protection with an instant-reaction mechanical chain brake and a stop claw keep you safe while you are working with the chainsaw. The rugged metal stop claw keeps the saw stable while you are working, and the ergonomic handle gives you a comfortable grip on the chainsaw. No tools are needed to adjust the chain tension or replace the chain. A big filler opening of the automatic chain lubrication system makes it easy to top it up if necessary. The set includes a fast charger and battery which can be used for all Power X-Change family products.

## **Features**

- Battery system Power X-Change
- Battery charge level indicator with 3 LEDs
- Battery can be used for other Power X-Change products
- High-quality chain and bar from OREGON
- Toolless chain tensioning and changing
- Ergonomic handle
- Sturdy stop claws made of metal
- Kickback protection with mechanical instant chain brake
- Big filler opening
- Automatic chain lubrication
- Chain catch bolt



## Technical Data

- Accumulator 18 V | 3000 mAh | Li-Ion - Charging time

- Sword length 250 mm - Max. cutting length 230 mm 4.3 m/s - Chain cutting speed 200 mL - Oil tank capacity - Number of accumulators 10 Pieces

## Logistic Data

- Width (mm) 225 mm - Gross weight (kg) 4.7 kg - Heigth (mm) 255 mm - Length (mm) 435 mm - Product weight (kg) 3.6 kg - Tool weight 3.6 kg - Gross Weight 4.7 kg

255 x 435 x 225 mm - Dimensions single packaging

- Pieces per export carton 2 Pieces - Gross weight export carton 10.6 kg

- Dimensions Export Carton 450 x 465 x 275 mm - Container quantity (20"/40"/40"HC) 960 | 1952 | 2196



















## Available as special accessories



Ersatzkette GC-LC 18 Li Chain Saw Accessory Item No.: 4501754 Bar Code: 4006825607024 Einhell Grey





18V 5,2 Ah Power-X-Change Battery Item No.: 4511357 Bar Code: 4006825598865 Einhell Accessory



18V 3,0 Ah Power-X-Change Battery Item No.: 4511341 Bar Code: 4006825590593 Einhell Accessory



Ersatzschwert GC-LC 18 Li Chain Saw Accessory Item No.: 4501753 Bar Code: 4006825607017 Einhell Grey

18V 30min Power-X-Change Power Tools Accessory Item No.: 4512011 Bar Code: 4006825587029 Einhell Accessory